## (1) 安装MySql

- 下载MySQL dmg 包, 从官网: http://www.mysql.com/downloads/ 进入, 点击下方的 DOWNLOADS: MySQL Community Server
- 安装, 此处设置的密码为root1234
- 配置环境变量
  - 1. 进入终端,输入: cd~
  - 2. 命令: touch .bash\_profile
  - 3. 命令: open -e .bash\_profile
  - 4. 新增加: export PATH = \${PATH}:/usr/local/mysql/bin
  - 5. 保存重新进入

## (2) MySql连接与断开

```
wangchundeMacBook-Pro:~ wangchun$ mysql -u root -p
Enter password:
Welcome to the MySQL monitor. Commands end with; or \g.
Your MySQL connection id is 11
Server version: 8.0.13 MySQL Community Server - GPL
Copyright (c) 2000, 2018, Oracle and/or its affiliates. All rights reserved.
Oracle is a registered trademark of Oracle Corporation and/or its
affiliates. Other names may be trademarks of their respective
owners.
Type 'help;' or '\h' for help. Type '\c' to clear the current input statement.
mysql> show databases;
+----+
l Database
+----+
I information_schema |
I mysql
I performance_schema I
+----+
4 rows in set (0.01 \text{ sec})
mysql> exit
Bye
wangchundeMacBook-Pro:~ wangchun$
```